SplashBlocker

How Are You Preventing Toilet Plume Aerosolization?



A Novel Clinical Safe Guard

Protecting Nurses, Caregivers, Visitors, Family Members and Healthcare Personnel

Reduce HAIs

- Easy To Use
- Increase Employee Safety Easy to Clean

Cost Efficient

Environmentally Friendly

SHBLOCKER

Toilet plume occurs when flushing aerosolizes pathogens. These plumes can travel up to 3 feet while in the air.

Uncovered plumes can cause lingering exposure to Chemotherapy drugs, C. diff, and Coronavirus.

Current plume management solutions are less environmentally friendly, less effective, and costly.



